


Funk-u-lator by Meridian

(Octaver - Synth - Autowah Filter)



- | | | | |
|-----------------------|-----------|------------------------------|---------------------|
| 1 - Clean Output | (-∞/+6Db) | 5 - Autowah Frequency Range | 7 - OC/Synth ON/OFF |
| 2 - Sub Octave Output | (-∞/+6Db) | 6 - Wah Effects Volume | 8 - Filter ON/OFF |
| 3 - Synth Output | (-∞/+6Db) | 7 - Filter Sensitivity | |
| 4 - Master Volume | | 8 - Master Volume(Clean+Wah) | |
| | | 9 - Type of Synth Wave | |

Controls

- 1,2 and 3 - Independent adjustments and can be activated by the octaver on/off switch.
- 4 - Master volume of octaver-synth side
- 5 - Adjusts the frequency range of the filter and it can be driven by external footswitch
- 6 - Adjusts the level of the Wha. (only the effect level)
- 7 - Adjusts the sensitivity of the filter
You need to adjust "ATTACK" depending on the strength of the picking
- 8 - Master volume of autowah side and adjusts the complete signal (clean+wah)
- 9 - Two positions switch. Soft and crunchy sound on the left and dirty and sharp sound on the right

Rear Panel

- | | |
|-------------------------|---------------------------------|
| INPUT Jack (MONO) | SWITCH 0Db/-6Db |
| OUTPUT Jack (MONO) | (Sets the octaver input signal) |
| Exp Pedal INPUT Jack | |
| DC adaptor Jack (DC 9v) | |

Power Supply

We Recommend using only power supplies for instruments.
(Meridian HPU ,Boss , One Spot etc...).

The use of a universal power supply may generate noises and malfunctions.

Meridian Declines any responsibility for the use of not suitable power supply.

Current Draw

100 mA (DC 9 V)

* **use only 9V DC stabilized adaptors**

Meridian

www.meridianguitars.com
info@meridianguitars.com